


## MODEL NO. 30.0219 100 Watt Speaker



Ab	le-2	<b>Part</b>	#
----	------	-------------	---

30.7211	Mounting Bracket
30.0251	Speaker Bell
30.0218	Tip
30.0230	Driver
30.0231 (not shown)	Replacement Voice Coil
40.0161	1'-16 Ga. GPT Wire
90.3063	Terminal
90.4219	1/ 4" x 1/ 2" Bolt
90.4525	1 7/ 8" x 1 3/ 8" Steel Washer
90.4540	Lock Washer
90.6996	Snap-in Grommet
90.6997	1 7/8" x 1 3/8" Fiber Washer
90.6998	1 5/ 16" x 3/ 4" Rubber Washer
90.6999	1 5/ 16" x 3/ 4" Fiber Washer

## \*IMPORTANT NOTE: WARRANTY DOES NOT COVER WATER DAMAGE\*

When mounting speaker, it is important to locate the drain hole at the bottom to allow for adequate drainage. If necessary, remove the driver from the bracket and rotate it. Failure to do so may cause water damage, resulting in speaker failure.



PRODUCTS COMPANY 804 East Hwy 248 Cassville, MO 65625 U.S. and Canada Toll Free Numbers Phone: 800-641-4098 FAX: 800-526-1240

**E-mail:** sales@able2products.com **WEB:** www.able2products.com